

Item Number
RAM-VB-131R4

RAM No-Drill™ Seat Bases

National Products, Inc.

Vehicle base for the

GMC SIERRA (DELUXE POWER SEATS)
(2000-2006)

GMC YUKON (DELUXE POWER SEATS)
(2000-2006)

CHEVY SILVERADO (DELUXE POWER SEATS)
(1999-2006)

CHEVY SUBURBAN (DELUXE POWER SEATS)
(2000-2006)

CHEVROLET 2500 & 3500 C/K SERIES TRUCK (DELUXE POWER SEATS) (2000-2006)

CHEVROLET AVALANCHE (2000-2006)

HUMMER H2 (2005-2006)

CADILLAC ESCALADE (2000-2006)

SPECIFICATIONS

Placement

Passenger side, in front, where seat frame meets floor board.

Drilling Required

None - uses existing seat bolts

Seat Configuration

Bucket

Construction/Finish

Steel/Black Powdercoat

Pole or Pedestal

Ordered Separately

Riser

Included

Weight 7.7 lbs.

Dimensions

Hole Center = 15"

Features

Installs in minutes with no drilling required
Won't interfere with levers, factory-installed console, or 4WD lever

Misc.

Rock solid construction
Lifetime warranty

National Products, Inc.
Phone: 206-763-8361
Fax: 206-763-9615
Address: 1205 S Orr St
Seattle, WA 98108
Website: www.ram-mount.com
Email: staff@ram-mount.com



Shown In Use



RAM-VB-131R4



Item Number
RAM-VB-131R4

RAM No-Drill™ Seat Bases

National Products, Inc.

Vehicle base for the

GMC SIERRA (DELUXE POWER SEATS)
(2000-2006)

GMC YUKON (DELUXE POWER SEATS)
(2000-2006)

CHEVY SILVERADO (DELUXE POWER SEATS)
(1999-2006)

CHEVY SUBURBAN (DELUXE POWER SEATS)
(2000-2006)

CHEVROLET 2500 & 3500 C/K SERIES TRUCK (DELUXE POWER SEATS) (2000-2006)

CHEVROLET AVALANCHE (2000-2006)

HUMMER H2 (2005-2006)

CADILLAC ESCALADE (2000-2006)

INSTALLATION INSTRUCTIONS

Note that attaching the riser prior to installing the base into the vehicle is suggested.

1. Move the passenger side seat to its rear most position.
2. Locate the two front seat frame nuts holding the passenger side seat to the floor board. The one closest to the passenger side door will be located within the seat track. The nut closest to the center of the vehicle may be under a piece of plastic trim but is located outside of the seat track toward the inside of the seat frame. Both have a star shape but can be loosened using a 15MM socket wrench.
3. Loosen the two nuts holding the front of the passenger side seat down. Only do so enough to pass the no drill base in between the seat tracks and floor board.
4. Once there is enough room for the base, slide the base under the seat so that the notches align with the seat studs projecting upward from the floor board. Make sure the back of each slos engages the seat studs.
5. Using the socket wrench, fully tighten the seat frame nuts to secure the base in place.

National Products, Inc.
Phone: 206-763-8361
Fax: 206-763-9615
Address: 1205 S Orr St
Seattle, WA 98108
Website: www.ram-mount.com
Email: staff@ram-mount.com

