

Item Number
RAM-VB-135MH1

RAM No-Drill™ Seat Bases

National Products, Inc.

Vehicle base for the HONDA ELEMENT (2003-NEWER)

SPECIFICATIONS

Placement

Passenger side on the floor, under front seat

Drilling Required

No - uses existing seat bolts

Seat Configuration

Bucket

Construction/Finish

Steel/Black Powdercoat

Pole or Pedestal

Sold Separately

Weight

5 lbs.

Dimensions

A = 18.5", B = 7.5", C = 1.875"

Hole Center = 15.875"

Features

Installs in minutes with no drilling required
Low profile keeps mount away from passenger leg space

Notes

The RAM-VB-135MH1 will not fit Honda Element vehicles with under seat speakers.

National Products, Inc.
Phone: 206-763-8361
Fax: 206-763-9615
Address: 1205 S Orr St
Seattle, WA 98108
Website: www.ram-mount.com
Email: staff@ram-mount.com



Shown In Use



RAM-VB-135MH1



Item Number
RAM-VB-135MH1

RAM No-Drill™ Seat Bases
National Products, Inc.

**Vehicle base for the
HONDA ELEMENT (2003-NEWER)**

INSTALLATION INSTRUCTIONS

1. Move the passenger seat back to its rearmost position and remove the front seat rail bolts. Store these bolts.
2. Place the supplied stand offs over the holes in the seat frame legs and rest the no drill base on top of these.
3. Align the holes in the base, stand offs, and seat frame legs with those in the floor board. The pedestal platform should be near the console.
4. Pass the supplied longer bolts with washers through to the holes in the floor board and start the thread by hand.
5. Using a socket wrench, fully tighten the bolts to secure the no drill base into the vehicle.
6. After a week of use, check seat bolts and re-tighten if necessary.

National Products, Inc.
Phone: 206-763-8361
Fax: 206-763-9615
Address: 1205 S Orr St
Seattle, WA 98108
Website: www.ram-mount.com
Email: staff@ram-mount.com

