

**Item Number**  
RAM-VB-161

# RAM No-Drill™ Seat Bases

National Products, Inc.

**Vehicle base for the**  
**FORD FREESTYLE (2005-NEWER)**  
**FORD FIVE HUNDRED (2005-2007)**  
**MERCURY MONTEGO (2005-NEWER)**  
**FORD TAURUS (2008)**

## **SPECIFICATIONS**

### **Placement**

Passenger side, in front, where seat frame meets floor board.

### **Drilling Required**

None - uses existing seat bolts

### **Seat Configuration**

Bucket

### **Construction/Finish**

Steel/Black Powdercoat

### **Pole or Pedestal**

Ordered Separately

### **Dimensions**

A = 18.375", B = 2.75", C = 1.5"

Hole Centers = 16.5"

### **Weight**

3.5 lbs.

## **Features**

Installs in minutes with no drilling required  
Won't interfere with levers or factory-installed console

## **Misc.**

Rock solid construction  
Lifetime warranty

---

National Products, Inc.  
Phone: 206-763-8361  
Fax: 206-763-9615  
Address: 1205 S Orr St  
Seattle, WA 98108  
Website: [www.ram-mount.com](http://www.ram-mount.com)  
Email: [staff@ram-mount.com](mailto:staff@ram-mount.com)



Shown In Use



RAM-VB-161



**Item Number**  
RAM-VB-161

**RAM No-Drill™ Seat Bases**  
National Products, Inc.

**Vehicle base for the**  
**FORD FREESTYLE (2005-NEWER)**  
**FORD FIVE HUNDRED (2005-2007)**  
**MERCURY MONTEGO (2005-NEWER)**  
**FORD TAURUS (2008)**

## **INSTALLATION INSTRUCTIONS**

For your vehicle base installation you will need a 13MM socket wrench.

1. Remove the two pieces of trim covering the inside and outside seat rail legs. These are located where the seat frame meets the floor board. Lift upward and forward toward the dash for easiest removal. Set these aside.
2. Using the 13MM socket, loosen the seat bolts holding the seat frame to the floor board. You need only loosen enough to pass the no drill base under the seat frame legs.
3. Once you have loosened both sides, slide the no drill base in between the seat frame leg and floor board. Slide the base toward the rear of the vehicle until the back of the slots touch the seat rail bolts.
4. Re-tighten the seat rail bolts.

Depending on the carpet and pad in your vehicle, replacing the two plastic trim pieces to their original position may not be possible. They may sit up approximately 1/8" due to the base under the seat frame leg. You may choose to leave these off and store them.

National Products, Inc.  
Phone: 206-763-8361  
Fax: 206-763-9615  
Address: 1205 S Orr St  
Seattle, WA 98108  
Website: [www.ram-mount.com](http://www.ram-mount.com)  
Email: [staff@ram-mount.com](mailto:staff@ram-mount.com)

