


# RAM-B-166 INSTRUCTION SHEET

## Parts Index

- A. RAP-224-1S (SUCTION CUP BASE)
- B. #10 X 3/4" LNG PH PD STST SHT MTL SCREW
- C. 2-7/16" X 1-5/16" BASE W/ POST
- D. DOUBLE SOCKET ARM



## STEP ONE

Align one 2-7/16" X 1-5/16" Diamond Base (C) on top of Suction Cup Base (A) and fasten with two screws (B).

## STEP TWO

Loosen knob on double socket arm (D) and attach to assembled unit in Step One.

## STEP THREE

Place remaining 2-7/16" X 1-5/16" Diamond Base (C) in open socket and tighten knob on double socket arm (D) for secure hold.

## STEP FOUR

Attach RAM Cradle (not included)



National Products, Inc., 1205 S. Orr St., Seattle, WA 98108, (206) 763-8361 [www.RAM-MOUNT.com](http://www.RAM-MOUNT.com)

